

Case Weight Variation Reduction and Subsequent Ballistic Dispersion Improvements in M118LR

Ms. Dionne Dillon

Manager, Manufacturing Engineering ,7.62mm and Cal .50

ATK Small Caliber Systems

May, 2010

OSR Approval #10-S-1445



Current Condition

- Demand For M118LR Increased 900% Between 2001 And 2009
- Considerable Field Experience Yielded Helpful User Feedback
 - Overall Quality And Performance Very Good
 - Accuracy And Consistency Typically Exceeds Specifications
- Some Users Requested Improvements
 - Improve Consistency Between Sublots
 - Reduce Need For Re-zero Between Sublots

Users – “Reduce Variation Between Sublots”

Project Objective:


Identify Process-Related Measures that Can Be Implemented at the Lake City Army Ammunition Plant To Improve Average Extreme Horizontal and Vertical Spreads and Reduce the Need to Re-zero Between Sublots



Continuous Improvement Philosophy

- M118LR Case Is Essentially Identical To An M80 7.62 Case Except For:
 - Primer Pocket Diameter
 - Head-stamp Requirements
 - Note 10 On M118LR Drawing

“Unit wt: 190-20 Grains. Case Weight Variation For Each Cartridge Sublot Shall Not Exceed 2 Grains After Taper.”



M118LR Cases Nearly Identical to M80 Cases

Why Is Note 10 There?


- Studies Show Relationship Between Case Volume, Pressure & Accuracy
- Minimize Case Volume Variation To Achieve The Best Accuracy
- Case Volume Can Be Correlated To Case Weight
- Case Weight Is Inherently Easier To Measure At High Production Levels
- Result Was Case Weight Variation Requirement


Control Case Weight For Best Performance

M118LR Case Manufacturing Process




A premier aerospace and defense company





Could M118LR Cases Be A Subset of M80 Cases?

- Weigh Random Samples Of M80 Cases
- Over A Long Period Of Time, Capture Differences In Brass Strip Gauge Variation
- Calculate The Proportion Of M80 Cases That Fall Into The Desired Weight Range



SPC Utilized To Measure Current M80 Process

M80 Case Weight Study Results





A premier aerospace and defense company

Process Capability

Process Data	
LSL	196
Target	*
USL	198
Sample Mean	197.02
Sample N	1200
StDev(Within)	0.973117
StDev(Overall)	1.15733

Exp. Overall Performance	
% < LSL	18.91
% > USL	19.86
% Total	38.76







- Data Collection And SPC Analysis Supported Changes
 - Different Raw Material Dimensions
 - Elimination Of 1 Draw, 1 Anneal, & 1 Trim Operation
 - M118LR And M80 Cases Are Now Manufactured Using The Same Process

M118LR Process Mimics Proven M80 Process



M118LR and M80 – Unified Process Flow




A premier aerospace and defense company



M118LR Cases Are The Same Weight In Every Sublot




LR Cases Come From The Center Of The Case Process



Vertical Spread – A Better Measurement



A premier aerospace and defense company



- M118LR Accuracy Was Improved
 - Reduced AEHS From 6.06 To 5.89
 - Reduced AEVS From 6.85 To 6.29
- Contributing To Less Variation In Point Of Impact Between Sublots



A More Consistent Product For The User



A premier aerospace and defense company

Dionne Dillon

ATK

816.796.5017

dionne.dillon@atk.com